


HFLL-RND

HANDS-FREE DUAL LED LIGHTS WITH 3 MODES



- 1 Step 1 – Unscrew to the direction of the arrow as shown on Figure 1 and remove both LED Lights from the flexible cable. See Figures 1 and 2.




Figure 1




Figure 2

- 2 Step 2 - Insert two [2] CR2032 batteries inside of each compartment according to the correct polarity. Note: Do not damage the copper contact on the side of the battery compartment. See Figure 3



Figure 3

- 3 Insert and screw the LED Lights to the direction of the arrow as shown on Figure 4




Figure 4

- 4 Step 4 - These LED Lights have three modes.

Mode 1 – Press the Power Button to switch on. This is Mode 1: High.



Figure 5: High Mode

Mode 2 – Press the Power Button again: Medium Mode.



Figure 6: Medium Mode

Mode 3 – Press the Power Button one more time: Strobe/Blinking Mode.



Figure 7: Strobe/Blinking Mode

Press the Power Button once more to switch-off the LED Lights.



Figure 8

Warning:

- Keep batteries out of reach of children
- Be sure to install batteries correctly according to the correct polarity (+/-)
- Batteries may explode when exposed to fire
- Use only CR2032 batteries for this product
- If you are not planning on using this product for an extended period of time, remove the batteries
- Do not install new batteries with used batteries
- Do not mix battery types (standard, rechargeable, or alkaline)
- Please recycle used batteries